





| Type | Description | Voltage (V) | Rated current (A) at 400V | Colour | Packing / Box (pcs) | Catalogue number |
|--------------|--|-------------|---------------------------|--------|---------------------|------------------|
| EL 2- BW3471 | Button round with spring reverse and LED indicator | 24V | 6 | red | 20 / 200 | 401474 |
| EL 2- BW3371 | | 24V | 6 | green | 20 / 200 | 401374 |
| EL 2- BW3571 | | 24V | 6 | yellow | 20 / 200 | 401574 |
| EL 2- BW3671 | | 24V | 6 | blue | 20 / 200 | 401674 |
| EL 2- BW3471 | | 110V | 6 | red | 20 / 200 | 401473 |
| EL 2- BW3371 | | 110V | 6 | green | 20 / 200 | 401373 |
| EL 2- BW3571 | | 110V | 6 | yellow | 20 / 200 | 401573 |
| EL 2- BW3671 | | 110V | 6 | blue | 20 / 200 | 401673 |
| EL 2- BW3471 | | 230V | 6 | red | 20 / 200 | 401471 |
| EL 2- BW3371 | | 230V | 6 | green | 20 / 200 | 401371 |
| EL 2- BW3571 | | 230V | 6 | yellow | 20 / 200 | 401571 |
| EL 2- BW3671 | | 230V | 6 | blue | 20 / 200 | 401671 |



| Type | Description | Type of contacts | Rated current (A) at 400V | Colour | Note | Packing / Box (pcs) | Catalogue number |
|-------------|--------------------|------------------|---------------------------|--------|----------------|---------------------|------------------|
| EL 2- BD 21 | Switch with arrest | 1NO | 6 | black | two-position | 20 / 200 | 401421 |
| EL 2- BD 33 | | 2NO | 6 | black | three-position | 20 / 200 | 401433 |



| Type | Description | Type of contacts | Rated current (A) at 400V | Colour | Note | Packing / Box (pcs) | Catalogue number |
|------------|---|------------------|---------------------------|--------|-----------------------|---------------------|------------------|
| EL2-BS 142 | Button with head "mushroom" type and with key | NC | 6 | red | release with spinning | 15/150 | 401142 |

